


Dash panel insert, rev counter, digital clock, instrument lighting control



- E 20 – Switches and instruments – lighting control
- G – Fuel gauge sender
- G 5 – Rev. counter
- K 8 – Fresh air blower warning lamp
- K 64 – Emergency light and right turn signal warning lamp
- K 65 – Left turn signal warning lamp
- L 8 – Clock light bulb
- T 6b – Connector 6 pin, black, in luggage boot, left
- T 26 – Connector 26 pin, yellow, on dash panel insert
- T 26a – Connector 26 pin, blue, on dash panel insert
- Y 2 – Digital clock
- Ⓣ – Earth connection, in tailgate wiring loom
- Ⓢ – Earth connection – 2 –, in dash panel wiring loom